ACCO-NT Conf

ACCO–NT Conf is a program for initial network configuration of the **ACCO–NT** access control panel, which enables the control panel to communicate with the ACCO server. The program allows local programming of the control panel network settings, as well as its time.

Power from the computer USB port is sufficient to supply the ACCO–NT control panel for the purpose of configuring by means of the ACCO–NT Conf program. After connecting the USB MINI–B socket on the control panel PCB with the computer USB port using a suitable cable, the Windows system will automatically detect connection of a new device and will install appropriate HID drivers for the new hardware. To maintain proper time settings of the control panel, be sure to insert the battery in it.

- local programming of the ACCO–NT control panel:
  - time settings
  - network settings in the memory (IP, netmask, gateway, DNS server, DHCP, server IP, port)
- reading data from the ACCO–NT control panel:
  - MAC address
  - firmware version
  - time settings
  - currently used network settings (IP address, netmask, gateway, DNS server, DHCP, server IP, port)
  - network settings in the memory (IP, netmask, gateway, DNS server, DHCP, server IP, port)

CE
The actual appearance of the products may differ from the presented images. Product descriptions are provided in the web service for information purposes only.