
Multipurpose Detector

AXD-200

Firmware version 1.07

EN



CE

axd-200_BW_en 08/26

SATEL sp. z o.o. • ul. Budowlanych 66 • 80-298 Gdańsk • POLAND
tel. +48 58 320 94 00
www.satel.pl

IMPORTANT

The device should be installed by qualified personnel.

Changes, modifications or repairs not authorized by the manufacturer shall void your rights under the warranty.

Description of symbols on the device:

The device meets the requirements of the applicable EU directives.

The device must not be disposed of with other municipal waste. It should be disposed of in accordance with the existing rules for environment protection (the device was placed on the market after 13 August 2005).

The device is designed for indoor installation.

The device meets the technical regulations of the Eurasian Customs Union.

SATEL aims to continually improve the quality of its products, which may result in changes in their technical specifications and software. Current information about the changes being introduced is available on our website.
Please visit us at:
https://support.satel.pl

Hereby, SATEL sp. z o.o. declares that the radio equipment type AXD-200 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.satel.pl/ce

Signs in this manual

Caution – information on the safety of users, devices, etc.

Note – suggestion or additional information.

CONTENTS

1. Features 2
2. Description 3
3. Installation 4
3.1 Tips for installation 5
3.2 Mounting 5
4. Test 8
5. Battery replacement 8
6. Specifications 9

The AXD-200 detector (Multipurpose Detector) can be used as:

- Shock detector – it detects shocks accompanying attempts to force open a door or window.
- Opening detector – it detects the opening of a door or window. You can connect a wired NC detector to it (e.g. a wired opening detector). The built-in opening sensor can be disabled.
- Shock and opening detector – it detects shocks accompanying attempts to force open a door or window. It also detects the opening of a door or window. You can connect a wired NC detector to it (e.g. a wired opening detector). The built-in opening sensor can be disabled.
- Flood detector – it detects indoor water flooding. The FPX-1 probe by SATEL is required. It must be purchased separately.
- Temperature sensor - it measures the air temperature.
- Roller shutter detector – it detects the opening of a door or window. You can connect to it a wired roller shutter detector and a wired NC detector (e.g. a wired opening detector).

The manual applies to the detector installed in the BE WAVE system.

1. Features

- Detecting shocks and vibrations. [*Shock detector* / *Shock and opening detector*]
- Detecting open door, window etc. [*Opening detector* / *Shock and opening detector* / *Roller shutter detector*]
- Input for connecting an NC type wired detector. [*Opening detector* / *Shock and opening detector* / *Roller shutter detector*]
- Input for connecting a wired roller shutter detector. [*Roller shutter detector]*
- Input for connecting the FPX-1 probe. [*Flood detector*]
- Capability to disable the built-in opening sensor. [*Opening detector* / *Shock and opening detector*]
- Operation in the 868 MHz frequency band.
- AES encrypted two-way radio communication.
- Transmission channel diversity – 4 channels for automatic selection of the one that will enable transmission without interference with other signals.
- Remote settings programming.
- Remote firmware update.
- Built-in temperature sensor (measuring range: -10°C...+55°C).
- LED indicator.
- Powered by CR123A 3 V battery.
- Battery status control.
- Tamper protection against enclosure opening and removal from mounting surface.
- A magnet for surface mounting and a magnet for flush mounting are provided (a magnet is used when the detector operates as *Opening detector*, *Shock and opening detector* or *Roller shutter detector*).

2. Description

Alarms

The circumstances in which the detector reports alarm depend on the selected detector type.

Shock detector

- after detecting a shock,
- after opening the tamper switch [tamper alarm].

Opening detector

- after moving the magnet away from the detector (opening the door or window),
- after opening the M1 input (violating the detector connected to the M1 input),
- after opening the tamper switch [tamper alarm].

Shock and opening detector

- after moving the magnet away from the detector (opening the door or window),
- after detecting a shock,
- after opening the M1 input (violating the detector connected to the M1 input),
- after opening the tamper switch [tamper alarm].

Flood detector

- after detecting flooding (water reaching the height at which the FPX-1 flood probe is installed),

The flood detector reports alarm and alarm restore with a delay of several seconds.

- after opening the tamper switch [tamper alarm].

Temperature sensor

- after opening the tamper switch [tamper alarm].

Roller shutter detector

- after moving the magnet away from the detector (opening the door or window),
- after opening / closing the roller blinds supervised by the roller shutter detector connected to the M2 input,
- after opening the M1 input (violating the detector connected to the M1 input),
- after opening the M2 input (no roller shutter detector) [tamper alarm],
- after opening the tamper switch [tamper alarm].

Electronics board

Do not remove the electronics board from the enclosure to avoid damage to the components on the board.




Figure 1 shows the inside of the detector after opening the enclosure.

① battery holder (CR123A 3 V).

② tamper switch.

③ terminals:

M1 - terminal for connecting a wired NC detector (*Opening detector* / *Shock and opening detector* / *Roller shutter detector*) or the FPX-1 flood probe (*Flood detector*).

COM - common ground.

M2 - terminal for:

– disabling the built-in opening sensor (*Opening detector* / *Shock and opening detector*). If you want to disable the built-in opening sensor, connect the M2 terminal to the COM terminal.

– connecting a roller shutter detector (*Roller shutter detector*).

By default, the M1 and COM terminals are shorted with a wire. Do not remove the wire if you are not planning to connect a wired detector or the flood probe to the terminals.

LED indicator

The LED indicator is flashing for about 10 seconds after inserting the battery. After that, it is only enabled while the diagnostics mode is started in the system. It indicates:

- periodical communication – short flash.
- alarm – ON for 2 seconds.

3. Installation

There is a danger of battery explosion when using a different battery than recommended by the manufacturer, or handling the battery improperly.

Do not crush the battery, cut it or expose it to high temperatures (throw it into the fire, put it in the oven, etc.).

Do not expose the battery to very low pressure due to the risk of battery explosion or leakage of flammable liquid or gas.

Be particularly careful during installation and replacement of the battery. The manufacturer is not liable for the consequences of incorrect installation of the battery.

If the detector is mounted higher than 2 meters above the ground, it may cause harm if it falls off.

3.1 Tips for installation

- The detector should be installed indoors, in spaces with normal air humidity.
- Do not install the detector outdoors.
- When selecting a place of installation, consider the radio communication range.
- Thick walls, metal partitions, etc. reduce the range of the radio signal.
- If you are using a double-sided mounting tape, remember to press it properly. Stick the tape to the device and keep pressing for several seconds, then stick the device to the surface and keep pressing for several seconds.


Opening detector / Shock and opening detector / Roller shutter detector

- Install the detector on the window / door frame (fixed surface). Install the detector in the upper part of the window frame. This will reduce the risk of flooding the detector when the window is tilted or open during rain.
- Install the magnet on the window / door (moving surface).
- Do not install the detector on ferromagnetic surfaces or in the vicinity of strong magnetic or electric fields.
- To connect a wired NC detector / roller shutter detector, use wires with a cross-section of 0.5-0.75 mm^2. The length of the wires should not exceed 3 m.

3.2 Mounting

The figures show the detector mounted vertically, but it may be mounted in any position (it has no effect on its operation).

1. Open the detector enclosure (Fig. 1). The enclosure opening tool, shown in the figure, is provided with the detector.



2. ***Opening detector / Shock and opening detector / Roller shutter detector***. If you want to connect a wired NC detector or a roller shutter detector:
   – make the opening for a cable in the enclosure base.


– run the detector cable through the opening.

3. ***Flood detector:***
   – make the opening for a cable in the enclosure base.
   – run the FPX-1 flood probe cable through the opening.


The FPX-1 flood probe must be purchased separately.

4. If the detector is to be mounted on the surface using a double-sided mounting tape (Fig. 3):
   – stick the tape to the enclosure base.
   – stick the enclosure base to the surface.

3



4



5. If the detector is to be mounted on the surface with screws:
   – place the enclosure base against the surface and mark the location of the mounting holes.
   – drill the holes in the surface for wall plugs (anchors). The wall plugs provided with the detector are intended for concrete or brick. For other types of surface (drywall, styrofoam), use other appropriately selected wall plugs.
   – secure the enclosure base to the surface with screws (Fig. 4).

If the detector is to detect removal from the surface, secure the detector with screws.


The detector must detect removal from the surface if it is to meet the requirements of Standard EN 50131 for Grade 2.

If the detector is to operate as the Shock detector *or* Shock and opening detector*, it is recommended to secure it to the surface with screws*.


6. ***Opening detector / Shock and opening detector / Roller shutter detector***. Install the magnet as shown in Figure 5. You can secure the surface magnet using a double-sided mounting tape or screws. You can use several spacers (Fig. 6). To make a hole for the flush magnet, use the ø9 mm drill bit.

*If you are planning to disable the built-in opening sensor, do not install the magnet (*Shock and opening detector*).*

5




6



7. ***Opening detector / Shock and opening detector:***
   – if you are connecting a wired NC detector, screw the detector wires to the COM and M1 terminals on the electronics board.
   – if you want to disable the built-in opening sensor, use a wire to connect the M2 and COM terminals.
8. ***Flood detector:***
   – secure the flood probe to the wall with screws (Fig. 7).
   – screw the probe wires to the COM and M1 terminals on the electronics board.

7



9. ***Roller shutter detector:***
   – screw the roller shutter detector wires to the COM and M2 terminals on the electronics board.
   – if you are connecting a wired NC detector, screw the detector wires to the COM and M1 terminals on the electronics board.
10. Add the detector to the system (see the manual for the BE WAVE system controller or the BE WAVE Hybrid system control panel). When a request to turn on the device will be displayed, install the battery in the detector.
11. Close the detector enclosure.

4. Test

1. Enable the diagnostics mode in the system (see the manual for the BE WAVE system controller or the BE WAVE Hybrid system control panel).
2. Depending on the detector type and its configuration, make sure that the LED indicator turns ON:
   – after impact against the surface protected by the detector, [*Shock detector*]
   – after moving the magnet away (opening the door or window), [*Opening detector / Shock and opening detector / Roller shutter detector*]
   – after violating the detector connected to the M1 input, [*Opening detector / Shock and opening detector / Roller shutter detector*]
   – after opening / closing roller blinds supervised by the roller shutter detector, [*Roller shutter detector*]
   – after submerging the FPX-1 probe in the water. [*Flood detector*]
3. Disable the diagnostics mode.

5. Battery replacement

The used batteries must not be discarded, but should be disposed of in accordance with the existing rules for environment protection.

The Be Wave app will indicate that the battery in the detector is low. The low battery should be replaced as soon as possible.

1. In the Be Wave app / BE WAVE Soft program, tap / click the room in which the detector is installed.
2. Tap / click the detector name.

3. Start the *Battery replacement* function.
4. Open the detector enclosure.
5. Remove the low battery.
6. Wait 1 minute.
7. Install the new battery.
8. Close the detector enclosure.
9. Start the *Unbypass device* function in the Be Wave app / BE WAVE Soft program.

6. Specifications

Operating frequency band ..... 868.0 MHz ÷ 868.6 MHz
Radio communication range (in open area) ..... up to 1300 m
Battery ..... CR123A 3 V
Battery life expectancy ..... up to 2 years
Standby current consumption ..... 55 µA
Low battery voltage threshold ..... 2.75 V
M1 input (NC) sensitivity ..... 240 ms
Temperature measurement range ..... -10°C...+55°C
Temperature measurement accuracy ..... ±1°C
Complied with standards ..... EN 50130-4, EN 50130-5, EN 50131-1, EN 50131-2-6, EN 50131-5-3
Security grade according to EN 50131-2-6 ..... Grade 2
Environmental class according to EN 50130-5 II
Operating temperature range ..... -10°C...+55°C
Maximum humidity ..... 93±3%
Enclosure dimensions ..... 20 x 102 x 23 mm
Surface mounted magnet enclosure dimensions ..... 15 x 52 x 6 mm
Surface mounted magnet spacer dimensions ..... 15 x 52 x 6 mm
Flush mounted magnet enclosure dimensions ..... ø10 x 28 mm
Weight ..... 59 g

Opening detector / Shock and opening detector / Roller shutter detector

Maximum gap
surface magnet ..... 20 mm
flush magnet ..... 18 mm

Shock detector / Shock and opening detector

Shock detection range (depending on the surface type) ..... up to 3 m

This range is for reference only. Please test the actual range when mounting the detector.